



PHILIPS



Special attention is subject to change without notice
© 2010 Koninklijke Philips N.V.
All rights reserved.

3000 0214801

English

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product online at www.philips.com/welcome.

1 Important

Read this user manual carefully before you use the appliance.

WARNING: Do not use this appliance near water.

When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk, even when the appliance is switched off.

WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

Always unplug the appliance after use.

If the insulation overheats, Unplug the appliance and let it cool down for a few minutes. Before you switch the appliance on again, check the grilles to make sure they are not blocked by hair or debris.

If the main cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

For additional protection, we recommend using a residual current device (RCD) in the electrical circuit that supplies the bathroom. This RCD must have a rated residual operating current not higher than 30mA. Ask your installer for advice.

Do not insert metal objects into the air grille to avoid electric shock.

Never block the air grilles.

Before you connect the appliance, ensure that the voltage indicated on the appliance corresponds to the local power voltage.

Do not use the appliance for any other purpose than described in this manual.

Do not use the appliance on artificial hair.

When the appliance is connected to the power, never leave it unattended.

Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.

Do not wind the main cord round the appliance.

Wait until the appliance has cooled down before store it.

Do not pull on the power cord after using. Always unplug the appliance and remove the plug.

Do not operate the appliance with wet hands.

Always return the appliance to a service centre authorized by Philips for examination or repair.

Repair by unqualified people could result in an extremely hazardous situation for the user.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable European Union regulations regarding exposure to electromagnetic fields.

Recycling

This symbol means that this product shall not be disposed of with normal household waste.

Follow your country's rules for the separation of waste materials. Please do not dispose of this product with other household waste. Correct disposal helps prevent negative consequences for the environment.

2 Introduction

This hair dryer is a new innovative hair dryer technology that replaces the Muroto Protect system. This technology has been specially designed to penetrate the hair shaft to provide a more effective drying performance. The temperature of the hair when dry, diagnosis your hair condition and the hair dryer will automatically adjust the heat to your hair needs.

This gives advanced protection to your hair.

With the help of the Muroto Protect system, the hair dryer can automatically detect the hair type and continuously dispense, reducing frizz and preventing static.

3 Overview

① Control panel

② Temperature settings

③ Airflow settings

④ Filter

⑤ Moisture protect button

⑥ Nozzle

⑦ Attachment

⑧ Air inlet grille

⑨ Heat diffuser

⑩ Diffuser

⑪ Hairdryer

⑫ Hairdryer

⑬ Diffuser

⑭ Diffuser

⑮ Diffuser

⑯ Diffuser

⑰ Diffuser

⑲ Diffuser

⑳ Diffuser

